


Installation Steps :

1. Plug your USB cable in to USB port of the USB HomeLAN Adapter.



2. Plug the other end of your USB cable in to the USB port of your PC.


3. Plug in the phone cable to the "RJ11" socket of your Ethernet Adapter.



4. Note:

PW: Power
LK: Link
RX: Collision
TX: Activity

5. Verifying your connection



Windows 98(SE) Driver Installation

1. Boot the system. Then the system will automatically detect a new USB Device and request you to install its driver.
2. Now Windows will begin the "Add New Hardware Wizard" and search for new drivers for "**USB HomeLAN Adapter**". Click "Next".
3. Select "Search for the best driver for your device. (Recommended)." — suggested to use. Click "Next" button.
4. Then insert the driver installation diskette/CD into the appropriate disk drive before continuing with the "Add New Hardware Wizard".
5. Windows driver file search for the device "**DM9601 USB To HomePNA Adapter**". Click "Next".
6. Windows finds your device model "**DM9601 USB To Fast Ethernet Adapter**". Click on the "Finish" button.
7. Restart your computer.

Windows ME Driver Installation

1. Boot the system. Then the system will automatically detect a new USB Device and request you to install its driver.
2. Now Windows will begin the "Add New Hardware Wizard" and search for new drivers for "**USB HomeLAN Adapter**". Click "Next".
3. Select "Specify the location of the driver [Advanced]". Click "Next".
4. Select "Search for the best driver for your device. (Recommended)." — suggested to use.
5. Then insert the driver installation diskette/CD into the appropriate disk drive before continuing with the "Add New Hardware Wizard".
6. Windows driver file search for the device "**DM9601 USB To HomePNA Adapter**". Click "Next".
7. Windows finds your device model "**DM9601 USB To Fast Ethernet Adapter**". Click on the "Finish" button.
8. Restart your computer.

Windows 2000 Driver Installation

1. Boot the system. Then the system will automatically detect a new USB Device and request you to install its driver.
2. Now Windows will begin the **"Found New Hardware Wizard"**. Click "Next".
3. Select **"Search for a suitable driver for my device (recommended)"** – suggested to use. Click "Next".
4. Then insert driver installation diskette/CD click the **"Browse"** button to specify the location of driver .Click "Next".
5. The wizard found a driver for the following device **"USB HomeLAN Adapter"**. Click **"Finish"**. Click "Next".
6. Windows finds your device model **"DM9601 USB To Fast Ethernet Adapter"**. Click **"Finish"**.
7. Now you've completed to install the drivers for the USB HomeLAN Adapter.

Windows XP Driver Installation

1. Boot the system. Then the system will automatically detect a new USB Device and request you to install its driver.
2. Now Windows will begin the **"Found New Hardware Wizard"**. Click "Next".
3. Select **"Install from a list or specific location"**. Click "Next".
4. Select **"Search for best driver in these location"** and select **"Include this location in the search"**.
5. Then Insert driver installation diskette/CD and click the **"Browse"** button to specify the location of driver .Click "Next".
6. The wizard will find your device model **"DM9601 USB To Fast Ethernet Adapter"** and install driver.
7. Then click **"finish"** to complete installation .

**1Mbps HomePNA
USB Adapter**

**Quick
Installation**

S/N: 312B2HU00002